

Instructions for 10K Decorator Temperature Sensor (FGD-0103)

Probe requires 22 gauge (or better) accessory wire.

Instructions for Express II

1. Use the included hex key to remove the cover
2. Remove any existing wires or sensors from the Sensaphone's input terminal
3. Place the corresponding input shunt in the "a" position
4. Program the input type for a 10K thermistor in either Fahrenheit or Celsius

Instructions for 1400, 1800, WEB600, Sentinel, Sentinel Pro and Stratus EMS

The probe may be connected to any available input/zone terminal. Refer to your user's manual for configuration and programming. To connect the probe:

1. Use the included hex key to remove the cover
2. Remove any existing wiring or sensors from the Sensaphone input terminal
3. Attach wires from the temperature sensor to the input terminal and ground terminal respectively

Warning: For use in dry environment only.

© 2007 Sensaphone 901 Tryens Road, Aston, PA 19014

For Technical Support call 877-373-2700 or E-mail support@sensaphone.com

10K

Decorator Temperature Sensor

LIT-0202